

POS.NO.	DESCRIPTION	ART.NO.
2	Grid lid (hinge 90 mm).....	65 002
2 A	Spring lock for grid lid.....	65 002A
3	Mixer drum, excl. mixer gate	65 003
4	Frame, complete w/wheels etc.	65 004
4 B	Bucket stand.....	65 004B
4 F	Frame, front part — below bucket stand.....	65 004F
4 L	Frame, front part — left side	65 004L
4 R	Frame, front part — right side	65 004R
4 T	Frame, top/rear part.....	65 004T
5	Loading wheel (1 pc.), 80 mm, excl. bolt.....	65 005
5 B	Bolt (1 pc.) for 80 mm loading wheel.....	65 005B
6	Wheel (1 pc.), 300 mm, excl. bolt.....	65 006
6 B	Bolt (1 pc.) for 300 mm wheel.....	65 006B
6 W	Washer (1 pc.) for 300 mm wheel.....	65 006W
7	Mixer gate incl. bolt.	65 007
8	Switch 8.0 Amp. w/thermal circuit breaker.....	65 008
8 K1	Piece for safety switch — a straight metal piece	65 008K1
8 K2	Metal hinge for fitting the safety switch.....	65 008K2
9	Mixer arm (1 pc.), Side.....	65 009
10	Mixer arm (1 pc.), Side-base	65 010
11	Mixer arm (1 pc.), Rake	65 011
12	Drive shaft	65 012
13	Gear motor 0,75 kW, 30 RPM, 230V	65 013
13 G	- Gear wo/motor	65 013G
13 M	- Motor wo/gear.....	65 013M
14	Starting capacitor 125 µF.....	65 014_100-125
15	Operating capacitor 25 µF.....	65 015_25
17 B	Telescopic leg (1 pc.), rear	65 017B
17 L	Telescopic leg (1 pc.), front — left side.....	65 017L
17 R	Telescopic leg (1 pc.), front — right side.....	65 017R
17 SB	Bolt and nut (1 set) for telescopic leg (1 pc.).....	65 017SB
19	Safety grid by the mixer gate	65 019
22	Mixer arms, 3 pcs, incl. cross joint.....	65 022
	Mixer arms, 3 pcs, excl. cross joint.....	65 022A
30	Discharge chute, incl. nuts	65 030
44	Cross joint for mixer arms, wo/rubber, incl. bolts.....	65 044
44 R	Replacement set for cross joint, rubber	65 044R

SPARE PART LIST - 65 LIGHT, 240V

GB-01.03.20

